

HEAVY DUTY L-BRACKET INSTRUCTIONS 8/13

Follow your cable instructions to attach cable to top box or brackets, plumb line to find location on wall you will need to install bracket. Lower threaded bolt to be able to access mounting holes. No hardware has been sent to attach bracket to wall, since wall surface may vary.



Once wall brackets are in place adjust threaded bolt back to its upper position.



Open set screw on bottom bolt to allow for the cable to feed through hollow bolt.



Once cable is in tighten set screw to secure cable.



Turn bottom bolt to place proper tension on cable. Once you have reached desired tension secure bottom nut so cable does not lose its tension.